



Tally Scoreboard

The Portable, Connected Game Scoring Device and Companion App

Setup and User Manual



Technical Specs

- Battery Life: Up to 8 hours continuous use
- Display: Outdoor-grade LED, anti-glare
- Range: 30 ft (9 m)
- Dimensions: 14" x 8" x 2"
- Weight: 2.2 lbs

Product Overview

Tally is a portable, connected digital scoreboard and companion app designed for use across points-based sports and recreational games. With the Tally companion app connected and synced with the Tally digital scoreboard, players enjoy enhanced play with real-time, simplified scoring.

Tally: Scoring Simplified

About Your Tally Board

Mounting Options

- **Option 1:** Utilize the integrated brackets for secure attachment to fences.
- **Option 2:** Extend the built-in stand for stable placement on flat surfaces.

Important: Always verify that the Tally Scoreboard is securely mounted before operation.

Charging

- Plug in the USB-C cable on the side of the board.
- A full charge takes approximately 3 hours.
- The LED indicator light will turn off once charging is complete.

Volume

- Adjust the volume using the + and - buttons located on the side of the scoreboard.
- Tally will save your last volume setting.

Powering On / Off

- **Power On:** Press the power button once and the LED display activates.
- **Power Off:** Press the power button again and the board will turn off.

LED Display Features

- High-contrast outdoor-visible LEDs.

Mounting Hooks



Flip-out Stand

USB Charging Port

Volume Controls

Power Button



What's In The Box

Tally Scoreboard Unit

USB-C Charging Cable

Quick Start Guide

Setup and User Manual

Safety & Precautions

Keep away from water and extreme temperatures. Do not open or modify the device. Keep out of reach of small children.



Play and Keep Score (Phone and Watch App)

Setup

1. Enable Bluetooth on your smartphone and smartwatch.
2. Open the Tally app on your phone and log on.
3. Open the Tally app on your watch.
4. Tap "Pair Device" on the main screen of the app or from the menu, select your Tally Scoreboard, and confirm pairing code.
5. Choose the sport you want to play or choose the quick play icon on the bottom of the main screen -or- click the "quick play" button on the bottom which repeats the last game and configuration.
6. Configure the game details by clicking "change default."
7. Optional: Change the team names.
8. Select the players by clicking on the player picture.
 - Choose the player from the list or create a new player by clicking the "add player" icon in the upper right hand corner.
9. Adjust the position of each player and which side serves first.
10. Click "Start Game".

Gameplay

1. Keep the Tally app open on your phone or watch.
2. Locate the "Score Line". This is the area of the app that contains the score.
3. Use simple swipe gestures on the score line on your phone or watch app to control the score of the game.
4. Score line gestures:
 - Swipe UP or DOWN toward the team who won the point to advance the score.
 - Swipe LEFT to undo the last point.
 - Swipe RIGHT to redo the last point.

Troubleshooting

Issue	Solution
Scoreboard not pairing	Reset Bluetooth settings, restart both devices
Score not updating	Ensure smartphone and Tally are within 30 feet of smartwatch
Battery draining fast	Reduce LED brightness
Incorrect score behavior	Check if correct sport mode is selected
Score Line not swiping up or down	Touch the center of the scoreline and then continue swiping

Warranty

Register Your Scoreboard



View Full Warranty Details

tallyscoreboard.com/warranty



Standard Warranty
1 Year



Warranty Coverage
Repair the product
Replace defective components



What's Not Covered
Unauthorized
modifications or repairs

Customer Support

Website: TallyScoreboard.com/contact-us

Email: tally@evolutesports.com

Phone: 724-775-7926

Hours: Mon-Thur 8am-6:30pm, Fri 8am-6pm EST